Installation Instructions

>>> Tub Spout Elbow - FIP Swivel Connection

Before installation, consult local and jurisdictional plumbing codes. Always install per local codes, using proper plumbing methods. Always test all connections before use.

Properly position tub spout elbow and hold copper fitting in place while tightening the brass swivel nut to tub/shower valve.

Caution: Do not swivel or move the tub ell after

tightening is complete.

Caution: Do not overtighten nut.

Caution: Do not use pipe thread sealant or pipe

tape on threads.

Caution: Failure to follow the instructions above may cause damage to the gasket and/or interfere with a

proper connection.

