


As Easy to Install as It Is to Use!

The innovative SinkTop Switch™ is an ideal solution for builders or remodelers looking for that touch of elegance that makes a new kitchen shine. And best of all, the UL-approved SinkTop Switch installs quickly and easily.

Here's How the SinkTop Switch Works:

The remote push button uses air pressure to activate the power module, located under the sink. When pressed, the SinkTop Switch sends a pulse of air down the air tube, triggers the remote switch and activates the disposer.



SinkTop Switch™ Kit Includes:

- Power module with cord
- 6-foot-long air tube
- Complete step-by-step installation instructions

SinkTop Switch™ Push Buttons

- Dual-outlet includes chrome and white
- Single-outlet includes satin nickel, chrome and white
- Other finishes available by special order




in sink erator

1.800.558.5700
www.insinkerator.com



Food waste disposers provide an environmentally responsible alternative to transporting food waste to landfills. And they can help reduce greenhouse gas emissions. At capable wastewater treatment plants, food waste can be converted to biosolids and used as fertilizer. Capable plants can also capture methane gas and recycle it as an energy source. (Check the plant in your area.)
www.insinkerator.com/green



EMERSON
Appliance Solutions

The Emerson logo is a trademark and service mark of Emerson Electric Co.

Insinkerator may make improvements and/or changes in the specifications of any time, in its sole discretion, without notice or obligation and further reserves the right to change or discontinue models.