

**919/LF919 Total Repair Kits - Current Assemblies**

Supports	Ordering Code	Model No.	
1/4" - 1/2"	<b>0888167</b>	<b>RK 919-T 1/4 - 1/2</b>	
<i>Kit Includes</i>			
Ordering Code	Model No.	Quantity	Description
0888130	RK 919-VT	1	1/4" - 1/2" 919 Total Relief Valve Repair Kit
0888110	RK 919-CK1	1	1/4" - 1/2" 919 First Check Valve Repair Kit
0888115	RK 919-CK2	1	1/4" - 1/2" 919 Second Check Valve Repair Kit

Supports	Ordering Code	Model No.	
3/4"	<b>0888168</b>	<b>RK 919-T 3/4</b>	
<i>Kit Includes</i>			
Ordering Code	Model No.	Quantity	Description
0888131	RK 919-VT	1	3/4" - 1" 919 Total Relief Valve Repair Kit
0888111	RK 919-CK1	1	3/4" 919 First Check Valve Repair Kit
0888116	RK 919-CK2	1	3/4" 919 Second Check Valve Repair Kit

Supports	Ordering Code	Model No.	
1"	<b>0888169</b>	<b>RK 919-T 1</b>	
<i>Kit Includes</i>			
Ordering Code	Model No.	Quantity	Description
0888131	RK 919-VT	1	3/4" - 1" 919 Total Relief Valve Repair Kit
0888112	RK 919-CK1	1	1" 919 First Check Valve Repair Kit
0888117	RK 919 CK2	1	1" 919 Second Check Valve Repair Kit

Supports	Ordering Code	Model No.	
1 1/4" - 1 1/2"	<b>0888170</b>	<b>RK 919-T 1 1/4 - 1 1/2</b>	
<i>Kit Includes</i>			
Ordering Code	Model No.	Quantity	Description
0888132	RK 919-VT	1	1 1/4" - 2" 919 Total Relief Valve Repair Kit
0888113	RK 919-CK1	1	1 1/4" - 1 1/2" 919 First Check Valve Repair Kit
0888118	RK 919-CK2	1	1 1/4" - 1 1/2" 919 Second Check Valve Repair Kit

Supports	Ordering Code	Model No.	
2"	<b>0888171</b>	<b>RK 919-T 2</b>	
<i>Kit Includes</i>			
Ordering Code	Model No.	Quantity	Description
0888132	RK 919-VT	1	1 1/4" - 2" 919 Total Relief Valve Repair Kit
0888114	RK 919-CK1	1	2" 919 First Check Valve Repair Kit
0888119	RK 919-CK2	1	2" 919 Second Check Valve Repair Kit

**909/LF909 Total Repair Kits - Current Assemblies**

Supports	Ordering Code	Model No.	
3/4" - 1"	<b>0794066</b>	<b>LFRK 909-T 3/4 - 1</b>	
<i>Kit Includes</i>			
Ordering Code	Model No.	Quantity	Description
0794059	RK 909-VT	1	3/4" - 1" 909 Total Relief Valve Repair Kit
0887120	RK 909-CK1	1	3/4" - 1" 909 First Check Valve Repair Kit
0887121	RK 909-CK2	1	3/4" - 1" 909 Second Check Valve Repair Kit

Supports	Ordering Code	Model No.	
1 1/4" - 2"	<b>0794071</b>	<b>LFRK 909M1-T 1 1/4 - 2</b>	
<i>Kit Includes</i>			
Ordering Code	Model No.	Quantity	Description
0794060	LFRK 909M1-VT	1	1 1/4" - 2" 909M1 Total Relief Valve Repair Kit
0794063	LFRK 909M1-CK1	1	1 1/4" - 2" 909M1 First Check Valve Repair Kit
0794064	LFRK 909M1-CK2	1	1 1/4" - 2" 909M1 Second Check Valve Repair Kit

**800M4/LF800M4/800M4FR/LF800M4FR Total Repair Kits - Current Assemblies**

Supports	Ordering Code	Model No.	
1/2" - 3/4"	<b>0887727</b>	<b>RK 800M4-T 1/2 - 3/4</b>	
<i>Kit Includes</i>			
Ordering Code	Model No.	Quantity	Description
0887703	RK 800M4-CK	1	1/2" - 3/4" 800M4 Check Valve Repair Kit
0887709	RK 800M4-V	1	1/2" - 3/4" 800M4 Vent Float Repair Kit
0887700	RK 800M4-B	1	1/2" - 3/4" 800M4 Bonnet Assembly Repair Kit
0887712	RK 800M4-S	1	1/2" - 3/4" 800M4 Seat Repair Kit

Supports	Ordering Code	Model No.	
1"	<b>0887728</b>	<b>RK 800M4-T 1</b>	
<i>Kit Includes</i>			
Ordering Code	Model No.	Quantity	Description
0887704	RK 800M4-CK	1	1" 800M4 Check Valve Repair Kit
0887710	RK 800M4-V	1	1" 800M4 Vent Float Repair Kit
0887701	RK 800M4-B	1	1" 800M4 Bonnet Assembly Repair Kit
0887713	RK 800M4-S	1	1" 800M4 Seat Repair Kit

Supports	Ordering Code	Model No.	
1 1/4" - 2"	<b>0887729</b>	<b>RK 800M4-T 1 1/4 - 2</b>	
<i>Kit Includes</i>			
Ordering Code	Model No.	Quantity	Description
0887705	RK 800M4-CK	1	1 1/4" - 2" 800M4 Check Valve Repair Kit
0887711	RK 800M4-V	1	1 1/4" - 2" 800M4 Vent Float Repair Kit
0887702	RK 800M4-B	1	1 1/4" - 2" 800M4 Bonnet Assembly Repair Kit
0887714	RK 800M4-S	1	1 1/4" - 2" 800M4 Seat Repair Kit

\*The wetted surface of this product contacted by consumable water contains less than 0.25% of lead by weight.



USA: T: (978) 689-6066 • F: (978) 975-8350 • Watts.com  
 Canada: T: (905) 332-4090 • F: (905) 332-7068 • Watts.com  
 Latin America: T: (52) 81-1001-8600 • Watts.com